

1/5





FIG. 1

HOST COMPUTER

NETWORK DEVICES

BROADCAST

"ADVISE MAC ADDRESS"



BROADCAST

"MAC ADDRESS IS 00-80-77-31-00-04"

PRINTER A



BROADCAST

"MAC ADDRESS IS 00-80-77-31-00-08"

PRINTER B



BROADCAST

"THE DEVICE HAVING THE MAC ADDRESS OF
00-80-77-31-00-04 SHOULD SET ITS IP
ADDRESS TO 133.151.12.34, ITS SUBNET
MASK TO 255.255.0.0, AND ITS DEFAULT
GATEWAY TO 133.151.1.1"



PRINTER A

PRIOR ART